

SALTSPRING ISLAND SAILING CLUB

One-time Club Rating Application



For a fee of \$15, a one-time Saltspring Island Sailing Club Rating will be assigned to all boats whose skippers do not present a valid 2008 PHRF-NW or PHRF-BC certificate with their registration form.

To facilitate the one-time SISC rating process, please complete the following form and mail it with your registration and any pre-2008 PHRF-NW/BC certificates for your boat.

Boat Name		Owner	Contact info... (phone; email)	
Standard Boat Class (e.g. Catalina 27, San Juan 24)			Year built	Designer
Rig <input type="checkbox"/> Masthead <input type="checkbox"/> Fractional <input type="checkbox"/> Other:		Engine <input type="checkbox"/> Inboard <input type="checkbox"/> Outboard		

Rig & Sail Dimensions

Please provide measurements in feet and inches

The Rig

I	Headsail hoist height measured from the deck (not the cabin top) to the top of the jib halyard sheave	
J	The "level" distance from the front of the mast to where the forestay is attached to the deck	
P	The length of the mainsail hoist: from the top of the boom to the "band" at the top of the mast	
E	The length of the mainsail foot length, from the back of the mast to the "band" near the end of the boom	

The Jib

Measure the biggest jib you will be using...

LLJ	The length of the jib from tack to head	
LP	The measurement perpendicular from the luff to the tack (the shortest measurement from front to back)	

The Main Sail

HB	The measured horizontal length of the headboard	
MGM	The mid-girth measurement of the mainsail, obtained by folding the sail in half — headboard to tack — and measuring along the resulting fold.	
MGU	The top quarter-girth measurement of the mainsail, obtained by folding the headboard of the sail to the mid-point of the luff (as obtained above) and measuring along the resulting fold.	

The Spinnaker

I don't have a spinnaker

LLS	The luff length of your spinnaker (assuming it's symmetrical)	
G	The widest measurement of the spinnaker, parallel to the foot line.	
SPL	The length of the spinnaker pole, from the front of the mast to the end of the pole.	
H	Spinnaker hoist height measured from the deck (not the cabin top) to the top of the spinnaker halyard sheave.	

Your boat's rating will be developed according to the PHRF-NW base data by the SISC Club Measurer. The rating is not subject to appeal. SISC reserves the right to conduct on-boat measurements and inspections.

SISC encourages all racers to join PHRF-NW. Applications and more information are available at www.phrf-nw.org.